


ARP

BOARD 1  
COMP SIDE



P23  
1 2 3 4 5 6

P24  
1 2 3 4 5 6

1 2 3 4 5 6  
P25

1 2 3 4 5 6  
P26

1 2 3 4 5 6  
P27

+15V

+15V

+15V  
GND  
-15V

CLOCK

START/  
STOP

S23  
RESET

RESET

OFF

SKIP S22

S2  
GATE  
TRIG

S1

S3  
STEP

RAND S21

SEQ

S4

8/2

16/1

S20

S19

S18

S17

S16

S15

S14

S13

S12

S11

S10

S9

S8

S7

S6

S5

GND

GND